

Activating SureTrack

SureTrack requires a one-time activation upon initial use.

i **NOTES:** You must have an Internet connection to access SureTrack. For additional information on Wi-Fi setup, refer to your diagnostic tool user manual.

These instructions may also be used in the future, for subsequent SureTrack activations after purchasing software upgrades.

1. Download and install the current Firefox web browser. Installation and support information are available on the Firefox website: www.mozilla.org
2. Open the Firefox browser and navigate to: www.ShopKeyPro.com

i **NOTE:** The SureTrack icon is not functional on this diagnostic tool.

3. Follow the illustrated steps below, and on the back page to complete the activation.

Activating SureTrack (continued on back)

The image displays two screenshots from the ShopKey5.com website. The top screenshot shows the homepage with a 'LOGIN' button in the top left corner, indicated by a circled '1' and an arrow. Below the navigation bar, there are sections for 'VINTAGE', 'COMMUNITY', and 'About ShopKey Pro'. The bottom screenshot shows the login and registration forms. The login form has fields for 'Username' and 'Password', a 'Forgot password? Click here to reset.' link, a 'Remember username & password' checkbox, and 'Login' and 'Cancel' buttons. A circled '2' and arrow point to the 'Login' button, and a dashed red box highlights the 'Create a new Individual Account' link. The registration form has fields for 'Email Address*', 'Name' (First Name*, Last Name*), 'Phone' (Phone Number), 'Address' (Address Line 1, Address Line 2), 'City*', 'State*', 'Zipcode', and 'Online Profile' (Username*, Password*, Retype Password*). A circled '3' and arrow point to the 'Email Address*' field, with the text 'Enter all required* information.' next to it. 'Cancel' and 'Create' buttons are at the bottom of the registration form.

Activating SureTrack (continued from front)

